TPA 玖钧传动 Motion Control

STEEL BASE LINEAR MODULES

钢基模组

详细代理商资料查询TPA官网 Please check TPA official website for detailed agent information

华东制造基地：East China manufacturing base:
电 话 Tel:0512-50127418
地 址：江苏省昆山市高新区莱斯路15号
Address: No.15 Laisi Road, High-tech Zone, Kunshan City, Jiangsu Province

华南制造基地：South China manufacturing base:
电 话 Tel:0755-84644758
地 址：深圳市坪山区坑梓街道金沙社区东联工业区5号玖钧产业园
Address: Jiujun Industrial Park, No.5 Donglian Industrial Zone, Jinsha Community, Kengzi Street, Pingshan District, Shenzhen City

山东制造基地：Shandong manufacturing base
地址：山东省济南市历城区 临港智能制造产业园7号 1号楼1#-A
Address:1# - A, Building 1, No. 7, Lingang Intelligent Manufacturing Industrial Park, Licheng District, Jinan City, Shandong Province

宁波制造基地：Ningbo manufacturing base
地 址：宁波市奉化区江口街道四明东路299号启迪工业园
Address: Tu Industrial Park, 299 Siming East Road, Jiangkou Street, Fenghua District, Ningbo City

上海分公司：Shanghai Branch
地 址：上海市松江区车墩镇北松公路5255号(智兆大厦)
Address: No.5255 Beisong Highway, Chedun Town, Songjiang District, Shanghai (Zhizhao Building)

北京办事处：Beijing office:
地 址：北京经济技术开发区科创十四街6号院1号楼
Address: Building 1, Yard 6, Kechuangshisi Street, Beijing Economic and Technological Development Zone

无锡办事处：Wuxi office:
地 址：无锡新吴区浩展大厦
Address: Haozhan Building, Xinwu District, Wuxi

浙江办事处：Zhejiang office:
地 址：浙江省绍兴市上虞区江扬路888号中富大厦
Address:Zhongfu Building, 888 Jiangyang Road, Shangyu District, Shaoxing City, Zhejiang Province, China

华中办事处：Central China office:
地 址：武汉市江夏区关南四路35号东港科技产业园
Address: Donggang Science and Technology Industrial Park, No.35 Guannansi Road, Jiangxia District, Wuhan City

东莞办事处：Dongguan office:
地 址：东莞市松山湖研发五路1号林润智谷6栋
Address: Building 6, Linrun Zhigu, No.1 R&D Fifth Road, Songshan Lake, Dongguan City

深圳办事处：Shenzhen office:
地 址：深圳市龙华区龙华街道龙观东路57号时代大厦
Address: Times building, No.57,Long Guan East rd, Longhua district, Shenzhen

版权所有※翻印必究 本型录内容如有变更，恕不另行通知，敬请谅解。 The contents of this catalogue are subject to change without prior notice.

TPA 网站 TPA website

微信公众号 Wechat public account

产品资料 Product Information

抖音号 Douyin

Solutions

ISO 9001

CE

产品型录编号:TPA-BD-ZE-004

TPA 玖钧传动·智造兴邦



玖钧传动·智造兴邦

维护保养手册

一、日常检查项目

线性模组是一种常见的传动机构，在实际操作中，被广泛应用到各种各样的设备中，因使用环境和使用工况不同，需要及时检查和维护。

日 常 检 查 项 目	
1. 检查部件表面是否有损伤，压痕和摩擦情况。	2. 滚珠螺杆、轨道、轴承是否有异常震动或噪音。
3. 电机、联轴器是否有异常震动或噪音。	4. 所见部位是否有不明粉尘、油渍、痕迹等。

二、周期维护项目

配 件	维 护 方 案	维 护 周 期	具 体 操 作
滚珠螺杆	增加润滑脂（粘度：30-40cts）清理旧油污，注入新润滑脂。	每月一次或每行走100KM的距离	用无尘布直接擦拭干净螺杆珠槽和螺母两端，将新润滑脂直接注入油孔或涂抹螺杆表面。
线性滑轨	增加润滑脂（粘度：30-150cts）清理旧油污，注入新润滑脂。	每月一次或每行走100KM的距离	用无尘布直接擦拭干净轨道表面及轨道珠槽，将新润滑脂直接注入油孔。

三、异常问题以及解决方法

线 性 模 组 异 常 情 况	维 修 、排 除 方 法
电源接入时产生异音	1. 调整伺服驱动器内参数“机械共振抑制”数值。 2. 调整伺服驱动器内参数“自动调谐”数值。
马达转动时产生异音	1. 调整伺服驱动器内参数“机械共振抑制”数值。 2. 调整伺服驱动器内参数“自动调谐”数值。 3. 检查马达刹车是否释放。 4. 检查机构是否因超载产生变形。
马达运转时滑台不顺畅	1. 检查刹车是否释放。 2. 将马达与线性模组分离，手推滑动座，判断问题点原因。 3. 检查联轴器固定螺丝是否松动。 4. 检查线性模组移动区域是否有异物掉落。
线性模组行走距离与实际距离不符	1. 检查输入行走数值是否正确。 2. 检查导程输入数值是否正确。
马达运动ON,滑台没有移动	1. 检查刹车是否释放。 2. 检查联轴器固定螺丝是否松动。 3. 将马达与线性模组分离，判断问题点、原因。

另本公司负责自身商品的故障维修，并不负责因产品故障引起的其他损失。

Maintenance manual

一、Daily inspection items

Linear module is a common transmission mechanism, which is widely used in all kinds of equipment in actual operation. It needs to be checked and maintained in time because of the different environment and working conditions.

Daily inspection items	
1.Check the surface of parts for damage, indentation and friction.	2.Is there any abnormal vibration or noise in the screw, track and bearing.
3.Whether the motor and coupling have abnormal vibration or noise.	4.See if there are any unknown dust, oil stains, traces, etc.

二、Periodic maintenance project

Parts	Maintenance scheme	Maintenance cycle	Specific operation
Ball screw	Add grease (viscosity: 30-40cts) Clean up old grease and inject new grease.	Once a month or every 100KM distance.	Clean the screw bead groove and both ends of the nut directly with a dust-free cloth, and directly inject new grease into the oil hole or coat the screw surface.
Linear slide rail	Add grease (viscosity: 30-150cts) Clean up old grease and inject new grease.	Once a month or every 100KM distance.	Clean the track surface and track bead groove directly with a dust-free cloth, and directly inject new grease into the oil hole.

三、Exceptions and solutions

Linear module abnormal situation	Maintenance and troubleshooting methods
Abnormal sound is produced when the power supply is connected.	1. Adjust the value of the servo drive parameter "mechanical resonance suppression". 2. Adjust the value of Auto tuning in the servo driver.
Abnormal sound is produced when the motor rotates.	1. Adjust the value of the servo drive parameter "mechanical resonance suppression". 2. Adjust the value of Auto tuning in the servo driver. 3. Check whether the motor brake release. 4. Check whether the mechanism is deformed due to overload.
The sliding table is not smooth when the motor is running.	1. Check the brake release. 2. Separate the motor from the linear module and push the sliding seat to determine the cause of the problem. 3. Check the coupling setting screws for loosening. 4. Check whether foreign objects have fallen from the moving area of the linear module.
The linear walking distance of the module is inconsistent with the actual distance.	1. Check whether the input walking value is correct. 2. Check whether the lead input value is correct.
The motor is ON, and the slide table does not move.	1. Check the brake release. 2. Check whether the coupling fixing screw is loose. 3. Separate the motor from the linear module to determine the cause of the problem.

In addition, the company is responsible for the fault maintenance of its own goods, and is not responsible for other losses caused by product failure.